# List of Warning/Indicator Lights

# Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.



(U.S.A.)

Brake system warning light



(Canada)

# Stop the vehicle immediately.



Charging system warning light

# Have the vehicle inspected immediately.



(U.S.A.)

Malfunction indicator lamp



(Canada)



SRS warning light



(U.S.A.)

"ABS" warning light



(Canada)

Electric power steering warning light



Pre-collision system warning light \*1



(Flashing and then continuously on)

# Follow the correction procedures.



Open door warning light



Low fuel level warning light



Driver's seat belt

(On the instrument panel)



Front passenger's seat belt reminder light

(On the center reminder light panel)



Tire pressure warning light \*2



Master warning light

For further information, refer to the Owner's Manual.

See the O	wner's Manual				
<b>++</b>	Turn signal indicator	R.	Radar cruise control indicator *1		
	Headlight high beam indicator	PnA	Intuitive parking assist-sensor indicator*1		
AUTO	Automatic high beam indicator *1	AFS OFF	"AFS OFF" indicator <sup>*1</sup>		
-\̈́\bar{\bar{\bar{\bar{\bar{\bar{\bar{\bar	Headlight indicator (U.S.A.)	22	Slip indicator		
=00=	Tail light indicator (Canada)	OFF	VSC off indicator		
却	Front fog light indicator		Electronically modulated air suspension indicator*1		
ECT SNOW	"ECT SNOW" indicator	ECO	Eco Driving Indicator Light		
LOCK	All-wheel drive lock indicator*1	PASSENGER AIR BAG ON OFF	SRS airbag on-off indicator*1		
	Cruise control indicator	AIR BAG AIR BAG OFF ON	SRS airbag on-off indicator*1		
For further information, refer to the Owner's Manual.					

<sup>\*1:</sup> If equipped
\*2: It also turn on due to natural causes such as natural air leaks or tire inflation pressure changes caused by temperature (the status of the full-sized spare tire, if equipped, is also checked). Adjust the tire inflation pressure.

### What to do if ...



# If the electronic key does not operate properly

# n Unlocking and locking the doors



To unlock or lock the vehicle, use the mechanical key. (driver's door only) The mechanical key is stored inside the electronic key.

- 1 Locks
- 2 Unlocks

# n Starting the engine





- 1 Depress the brake pedal.
- 2 Touch the Lexus emblem side of the electronic key to the "ENGINE START STOP" switch.
- 3 Press the "ENGINE START STOP" switch within 10 seconds of the buzzer, keeping the brake pedal depressed.
- \*: If equipped

If the electronic key battery becomes depleted, replace it with a new battery. For instructions on replacing the battery, refer to the Owner's Manual. If you need further assistance, contact your Lexus dealer.

# If the engine doesn't start

Make sure that the correct operating procedures have been followed.

## Brake pedal

Steering wheel lock

Make sure that the brake pedal is firmly depressed when attempting to start the engine.

Make sure that the steering wheel lock is released.

To release it, press the "ENGINE START STOP" switch while gently turning the wheel left or right.

If the engine still does not start, see the Owner's Manual for more information or contact your Lexus dealer.

# **Electronic Key Alarm**

The electronic key alarm uses an alarm and warning messages to indicate that the electronic key has been used improperly. Take appropriate measure in response to any warning messages that are displayed. In some cases, an alarm may sound without an accompanying warning message. If so, follow the correction procedure in the table below.

Alarm	Situation	Correction procedure
Exterior alarm sounds once for 10 seconds.	An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.
Interior alarm pings continuously.	The "ENGINE START STOP" switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the "ENGINE START STOP" switch was in ACCESSORY mode).	Close the driver's door.
	The "ENGINE START STOP" switch was turned OFF while the driver's door was open.	Close the driver's door.